

Customer Name:	Bell	PAG No.:	WF0701AX
Surveyor Name:	Mr David Richards	Surveyor Code:	DR123

To ensure the installers have the correct WHITE trims, Specify the main trim required for the installation

Description	Ref	Length	Quantity	Description	Ref	Length	Quantity
28 x 6 S/E Trim	KW0316W	3M	10	12mm Quadrant	KW0317W	3M	4
28 x 6 S/E Trim	KW0311W	5M		12mm Quadrant	KW0309W	5M	
40 x 7 S/E Trim	KW0930W	3M		19mm Quadrant	KW0929W	3M	
40 x 7 S/E Trim	KW0927W	5M		19mm Quadrant	KW0924W	5M	
60 x 7 S/E Trim	KW0933W	3M		25 x 20 Packing	KW0937W	3M	
60 x 7 S/E Trim	KW0932W	5M		25 x 20 Packing	KW0936W	5M	
90 x 7 S/E Trim	KW0935W	3M		15 x 20 Multi Angle	KW0939W	3M	
90 x 7 S/E Trim	KW0934W	5M		15 x 20 Multi Angle	KW0938W	5M	
28 x 6 D/E Trim	KW0931W	3M		70mm Ogee Trim	KW0942	5M	6
28 x 6 D/E Trim	KW0928W	5M		125mm Ogee Trim	KW0943	5M	

The following instructions should be read in conjunction with the installation manual

Frame Locations and frame numbers as shown on DS217 print outs.

No face seal to face brickwork.

Pvc-u Box sash windows.

Remove All old box, Linings & architraives.

New windows to fit behind brickwork.

Flat trim on brickwork outside.

70mm ogee architraves inside.